



## 1802337 NEW [Camshaft w/o Gear & w/o Lifters]

Instruction Guide

**This camshaft is ground to late specification.**

1. Intake and exhaust valve lash are to be the same - .025"
2. Install camshaft with the new lifters
3. Install the enclosed valve clearance specification sticker on the valve cover above #1 cylinder

