

IF PUTTING IN “SPEAKER GRILLS” FOLLOW THIS PROCEDURE BEFORE INSTALLING THE HEADLINER

To attach your old Speaker Grill onto the new headliner:

1. With a sharp blade, from the backside of the new headliner, carefully cut through the 4 slits that are around each speaker area
2. Cut carefully through the fabric and foam around the entire “rectangle plastic” piece. Remove this piece of fabric and plastic
3. Your Speaker Grill clips into the 4 slits in the plastic, from the front side of the headliner

IF YOU DO NOT HAVE SPEAKER GRILL COVERS, FOLLOW THIS PROCEDURE BEFORE INSTALLING THE HEADLINER

1. Very carefully, peel away the plastic rectangle piece on the backside of the headliner. The fabric will stretch and sag easily, so you must gently ease the plastic off the fabric to reduce the stretching and sagging
2. **Do not cut through the fabric, removing the plastic rectangle piece will allow the sound to come through the fabric**

