



HA353657A1HL KIT [CREE LED Cab Roof Light Kit, (Pkg. of 6)]

Instruction Guide

1. Remove bezel (including OE light) from machine
2. Release original light from machine bezel and disconnect electrical connector
3. Place the new Hy-Cap lights into the bezel from the front
4. Secure by inserting the (4) cap screws (provided) from the rear
5. Replace bezel (with lights intact) onto machine and secure hardware

