



HR330061 [CREE LED Flood Beam Front Upper Mid-Body Light, 3000 Lumens]

Instruction Guide

This light is designed to accommodate left or right-side applications

1. Remove original light from machine mounting bracket
2. Disconnect light wiring connector
3. Place spacers (provided) into bracket of new light. Holding spacers in place, position new light under the OE bracket and insert carriage bolt. Install nut & washer
 - a. Be cautious not to let spacers fall to the ground
4. If needed, install the provided electrical connector onto machine wires
5. Position beam to desired direction & secure hardware

