

- 1. Remove original seat and suspension
- 2. Cap all hydraulic lines with 2 female and 2 male 9/16" JIC Plugs
- 3. Attach Riser Brackets to cab flood using four 5/16" x 1" bolts, lock washers and nuts
- 4. Place adapter plate on support bracket and drill four 5/16" holes into compartment
- 5. Attach adapter plate to support bracket using four each 5/16" x 2" bolts, 1" tube spacer, lock washer and nuts
- 6. Attach suspension to adapter plate using four  $-5/16'' \times 1''$  bolts, spacer nut washers and nuts
- 7. Attach seat to suspension using four  $-5x16'' \times 1''$  bolts, lock washers and nuts

