


Adjustment Instructions



All measurements are taken after clutch assembly is bolted to the flywheel.

A = Measurement is from the disk blank to the transmission release lever – 1.589" (approx.)

A1 = Measurement is from the disc blank to the PTO release lever – 2.574" (approx.)

