


## Adjustment Instructions



### Flywheel Step – Flat

All measurements are taken after clutch assembly is bolted to the flywheel.

D = Measurement is from the flywheel mounting surface to the release lever – 3.780"

D1 = Measurement is from the flywheel mounting surface to the release lever – 4.760"

