



HA92267 [CREE LED Flood Beam Lamp, 3200 Lumens]

Instruction Guide

This lamp is designed to accommodate left or right-side applications:

1. Remove original lamp from machine
2. Install bracket onto lamp
3. Feed wires through grommet in fender or cab if needed
4. Install connector housing as needed (should match wiring of connector on machine)
5. Install lamp onto machine
6. Adjust beam to be desired direction, secure hardware

