

FC563U NEW [11" Single Stage Pressure Plate,

w/1-7/8" 29 Spline Hub - New]

Instruction Guide

Borg Beck Clutch Information

The primary cause of lever strut displacement has been identified as the release lever or release lever plates being pulled away from the flywheel, putting excess pressure on the antirattle spring. This results in the strut being left in a "free" position and will cause it to fall out of the correct pivot position. One or more release levers positioned higher than the other would indicate a strut being out of position. If this problem is not corrected, the clutch will not function properly. Please call our Service Department if you identify this issue.

