



## 8302244 [LED Flasher Module]

### Instruction Guide

1. Install Flasher Relay Unit with the Red wire leading to the power source and the Grey wire leading to the lamp. Reversing these wires will result in a constant beam
2. If multiple lamps are wired in-line, the flasher must be installed in-line prior to first lamp in the circuit

